

## Singing Harp

Purchase 1"x10"x8' pine wood to make the sound board of the harp. Purchase ¼" round shoe molding to make the bridges of the harp. Purchase eyelet screws to connect the wire. Purchase a roll of fine wire to make the strings.

Cut the 8' pine into 10" sections. If desired these sections may be cut into trapezoid shape as shown in Figure 1 below. Lightly sand the sections to remove any splinters. The sections may be stained if desired. Cut the shoe molding into 8" strips. Use two strips per harp to form the two bridges. Glue and finish nail the bridge strips as shown in Figure 1.

Drill 8, 1/32" starter holes at 1" intervals and screw into place the eyelets. Attach the wire to one eyelet and run across the two bridges to the eyelet on the opposite side.

Tighten the eyelets to tune each string. Paint "Singing Harp of David" on the main board.

